


# ET-4/ET-5 USER INSTRUCTIONS

1. Assemble the button receiver and eartip to the acoustic tube as shown.
2. Insert the eartip into your ear and run the tube over the back of your shirt collar or some other inconspicuous location.
3. Plug in the button receiver cord and adjust volume as desired.



**ET-4 Shown**

---

**TELEX®**

---

TELEX COMMUNICATIONS, INC. • 9600 Aldrich Ave. So., Minneapolis, MN 55420 U.S.A.